

DESCRIPTION

OKM TRANSFER PAPER is a decoration sheet that can be transferred to different types of material such as polyethylene, polypropylene, eva, microfibers...



USE STEPS

- 1- If you want to use plastic, put it in the oven to the temperature that the plastic needs for being thermoformed.
- 2- Cut from the roll the paper quantity that you need for the piece that you want to decorate. Remember to leave a tab on one side, for better take out of the paper.

- 3- When the plastic is ready for use, we open the oven, and we put on the plastic the transfer paper, starting on one side and we go down to the other side, ensuring with the hand the paper is well placed.
- 4- We make pressure with the hand in the entire paper surface, to help the ink transfer in the plastic. This process takes more or less around 50"-60".
- 5- We recommend before taking out the paper, put the set (plastic + paper), again in the oven around 20-30", because in the transferring process the plastic lose the right temperature for making the vacuum.
- 6- The transferring is completed, so you take the tab and stretch the paper.
The decorated plastic is finished, and it's ready to thermoform.

INFORMATION

For more information you can contact us in our e-mail address: okm@okm.es or in our telephone number: +34 972 677 095.

You can look all the available designs in our web page: www.okm.es or consulting to our commercials.